

GX-235 ストップリスト

PEDAL

32 CONTRA VIOLONE
16 PRINCIPAL
16 BOURDON
16 LIEBLICH BOURDON (SW)
16 VIOLONE
8 OCTAVE
8 FLUTE
4 SUPER OCTAVE
MIXTURE IV
16 BOMBARDE
8 TROMPETTE
4 CLARION
GENISYS VOICE 1 (OPTIONAL)
GENISYS VOICE 2 (OPTIONAL)

SWELL

8 ROHR BOURDON
8 VIOLE
8 VOIX CELESTE
4 GEIGEN OCTAVE
4 TRAVERSE FLUTE
2-2/3 NASARD
2 PICCOLO
1-3/5 TIERCE
PLEIN-JEU IV
16 BASSON
8 SWELL FESTIVAL TRUMPET (NC)
8 TROMPETTE
8 HAUTBOIS
TREMULANT
CELESTA
SWELL UNISON OFF
GENISYS VOICE 3 (OPTIONAL)
GENISYS VOICE 4 (OPTIONAL)

GREAT

16 VIOLONE
8 PRINCIPAL
8 HARMONIC FLUTE
8 VIOLE (SW)
8 FLUTE DOLCE CELESTE II (SW)
4 OCTAVE
4 FLUTE
2 FIFTEENTH
MIXTURE IV
CYMBALE III
8 FESTIVAL TRUMPET (NC)
8 TROMBA
8 KRUMMHORN
TREMULANT
CELESTA (SW)
CHIMES
GENISYS VOICE 5 (OPTIONAL)
GENISYS VOICE 6 (OPTIONAL)

COUPLERS

8 GREAT TO PEDAL
8 SWELL TO PEDAL
8 SWELL TO GREAT

GENERAL

BASS COUPLER
MELODY COUPLER
ALTERNATE TUNING
GENISYS VOICES COUPLE
TREMULANTS FULL

ANTIPHONAL

SWELL MAINS OFF
SWELL TO ANTIPHONAL
GT-PD MAINS OFF
GT-PD TO ANTIPHONAL

MIDI

MIDI ON PEDAL
MIDI ON SWELL
MIDI ON GREAT