

## GX-335 ストップリスト

### **PEDAL**

32 CONTRA VIOLONE  
16 PRINCIPAL  
16 BOURDON  
16 BOURDON DOUX (SW)  
16 VIOLONE  
8 OCTAVE  
8 GEDACKT  
4 SUPER OCTAVE  
MIXTURE IV  
16 BOMBARDE  
8 TROMPETTE  
4 CLARION  
GENISYS VOICE 1 (OPTIONAL)  
GENISYS VOICE 2 (OPTIONAL)

### **SWELL**

8 ROHR BOURDON  
8 VIOLE  
8 VOIX CELESTE  
4 GEIGEN OCTAVE  
4 FLÛTE  
2-2/3 NASARD  
2 OCTAVIN  
1-3/5 TIERCE  
PLEIN-JEU IV  
16 BASSON  
8 TROMPETTE  
8 HAUTBOIS  
TREMULANT  
SWELL UNISON OFF  
GENISYS VOICE 3 (OPTIONAL)  
GENISYS VOICE 4 (OPTIONAL)

### **GREAT**

16 VIOLONE  
8 PRINCIPAL  
8 HARMONIC FLUTE  
8 FLUTE CELESTE II (SW)  
8 VIOLE (SW)  
4 OCTAVE  
4 SPIRE FLUTE  
2 FIFTEENTH  
MIXTURE IV  
8 TRUMPET  
CHIMES  
TREMULANT  
GENISYS VOICE 5 (OPTIONAL)  
GENISYS VOICE 6 (OPTIONAL)

### **POSITIV**

8 HOLZ GEDACKT  
4 PRINZIPAL  
4 KOPPELFLÖTE  
2 OKTAV  
1-1/3 QUINTFLÖTE  
MIXTURE III  
8 KRUMMHORN  
POSITIV UNISON OFF  
POSITIV UNENCLOSED  
GT-PO MANUAL TRANSFER  
ANITIPHONAL ORGAN ON  
MAIN ORGAN OFF  
TREMULANT  
GENISYS VOICE 7 (OPTIONAL)  
GENISYS VOICE 8 (OPTIONAL)

### **COUPLERS**

8 GREAT TO PEDAL  
8 SWELL TO PEDAL  
8 POSITIV TO PEDAL  
8 SWELL TO GREAT  
8 POSITIV TO GREAT  
8 SWELL TO POSITIV  
BASS COUPLER  
GENISYS VOICES COUPLE

### **GENERAL**

TREMULANTS FULL  
MELODY COUPLER PO>GT  
ALTERNATE TUNING

### **MIDI**

MIDI ON PEDAL  
MIDI ON SWELL  
MIDI ON GREAT  
MIDI ON POSITIV  
MIDI ON SWELL  
MIDI ON GREAT