

GX-350 ストップリスト

PEDAL

32 CONTRA VIOLONE
16 DIAPASON
16 BOURDON
16 BOURDON DOUX (SW)
16 VIOLONE (GT)
8 OCTAVE
8 GEDACKT FLÖTE
4 CHORALBASS
4 FLUTE
MIXTURE IV
32 CONTRE BOMBARDE
16 BOMBARDE
16 CONTRE TROMPETTE (SW)
8 TRUMPET
4 CLARION
GENISYS VOICE 1 (OPTIONAL)
GENISYS VOICE 2 (OPTIONAL)

SWELL

16 BOURDON DOUX
8 ROHR BOURDON
8 FLUTE CELESTE II
8 VIOLA POMPOSA
8 VIOLA CELESTE
4 OCTAVE GEIGEN
4 TRAVERSE FLUTE
2-2/3 NASARD [4 ORCH. FLUTE]
2 PICCOLO [8 CLARINET]
1-3/5 TIERCE [8 FRENCH HORN]
FOURNITURE IV
16 CONTRE TROMPETTE
8 TROMPETTE
8 OBOE
8 VOX HUMANA [COR ANGLAIS]
4 CLAIRON
CELESTA
16 SWELL
UNISON OFF
4 SWELL
TREMULANT
SWELL SOLO VOICES ON
GENISYS VOICE 3 (OPTIONAL)
GENISYS VOICE 4 (OPTIONAL)

[]内は、Swellのソロボイス

GREAT

16 VIOLONE
8 DIAPASON
8 HARMONIC FLUTE
8 BOURDON
8 GAMBA
4 OCTAVE
4 FLUTE
2-2/3 TWELFTH
2 FIFTEENTH
MIXTURE IV
CYMBALE III
8 TROMBA
CHIMES
TREMULANT
GENISYS VOICE 5 (OPTIONAL)
GENISYS VOICE 6 (OPTIONAL)
GT-PD UNENCLOSED
MELODY COUPLER CH>GT
BASS COUPLER

CHOIR

16 ERZÄHLER
8 HOLZ GEDACKT
8 ERZÄHLER
8 ERZÄHLER CELESTE
4 PRINZIPAL
4 KOPPELFLÖTE
4 ERZÄHLER CELESTE II
2 OKTAV
1-1/3 QUINTFLÖTE
ZIMBEL III
16 RANKETT
8 FESTIVAL TRUMPET
8 KRUMMHORN
TREMULANT
GENISYS VOICE 7 (OPTIONAL)
GENISYS VOICE 8 (OPTIONAL)
CHOIR UNENCLOSED

GENERAL

SWELL MAINS OFF
SWELL TO ANTIPHONAL
GT-CH-PD MAINS OFF
GT-CH-PD TO ANTIPHONAL
GT-CH MANUAL TRANSFER
TREMULANTS FULL
ALTERNATE TUNING

COUPLERS

8 GREAT TO PEDAL
8 SWELL TO PEDAL
4 SWELL TO PEDAL
8 CHOIR TO PEDAL
16 SWELL TO GREAT
8 SWELL TO GREAT
4 SWELL TO GREAT
8 CHOIR TO GREAT
16 SWELL TO CHOIR
8 SWELL TO CHOIR
4 SWELL TO CHOIR
GENISYS VOICES (OPTIONAL)

MIDI

MIDI ON PEDAL
MIDI ON SWELL
MIDI ON GREAT
MIDI ON CHOIR